



PPTP on Apple iPad


This document contains instructions for configuring and connecting via PPTP for GTA Firewalls.

Configuring

1. Launch Settings.
2. Navigage to General > Network > VPN.
3. Select Add VPN Configuration.




4. Select PPTP.






5. Enter a Description.




6. Enter the Server Address (this is the firewall IP Address or Resolvable Name).







7. Enter the Account (this is your Users Identity from the firewall).



8. Enter the Password (this is your Users L2TP/PPTP password).



9. Slide Send All Traffic to OFF.



10. Select Save.



Connecting

1. Go to Settings > General > Network > VPN.



2. Slide VPN to ON.

